

# FLAT ELBOWS

## I-Beam 90° Flat Elbow



Part Number	Dimensions (")					
	W	R	A	B	X	Y
I6-20C-FE90-6-12R-⊕	6	12	18	18	22	22
I6-20C-FE90-9-12R-⊕	9	12	20	20	25	25
I6-20C-FE90-12-12R-⊕	12	12	21	21	28	28
I6-20C-FE90-18-12R-⊕	18	12	24	24	34	34
I6-20C-FE90-24-12R-⊕	24	12	27	27	40	40
I6-20C-FE90-30-12R-⊕	30	12	30	30	46	46
I6-20C-FE90-36-12R-⊕	36	12	33	33	52	52
I6-20C-FE90-6-24R-⊕	6	24	30	30	34	34
I6-20C-FE90-9-24R-⊕	9	24	32	32	37	37
I6-20C-FE90-12-24R-⊕	12	24	33	33	40	40
I6-20C-FE90-18-24R-⊕	18	24	36	36	46	46
I6-20C-FE90-24-24R-⊕	24	24	39	39	52	52
I6-20C-FE90-30-24R-⊕	30	24	42	42	58	58
I6-20C-FE90-36-24R-⊕	36	24	45	45	64	64
I6-20C-FE90-6-36R-⊕	6	36	42	42	46	46
I6-20C-FE90-9-36R-⊕	9	36	44	44	49	49
I6-20C-FE90-12-36R-⊕	12	36	45	45	52	52
I6-20C-FE90-18-36R-⊕	18	36	48	48	58	58
I6-20C-FE90-24-36R-⊕	24	36	51	51	64	64
I6-20C-FE90-30-36R-⊕	30	36	54	54	70	70
I6-20C-FE90-36-36R-⊕	36	36	57	57	76	76

Supplied with:



Material Configurations:

